

))) FirstLook[™]

User's Guide

FirstLook Automotive Engine Diagnostic Sensor "The Pulse of Your Engine"

Model ADS ES 100

Table of Contents

<u>Section</u>	<u>Page</u>
1. Introduction	2
2. Overview	2
3. Theory of Operation	2
4. Sensor Setup	3
5. Lab Scope Basics	4
6. Quick Tests	5
7. Triggered Tests	8
8. Automotive Engine Timing Chart	13
9. Waveform Analysis	18
10. Support and Warranty	22

**SenX Technology, LLC
784 South Poseyville Road
Midland, MI 48640
Phone 989-832-8898
Fax 989-832-8908**

FirstLook[™] is a trademark of SenX Technology, LLC
SenX[™] is a trademark of SenX Technology, LLC

U.S. Patent No. 6,484,589
Made in the U.S.A.

**Copyright 2002 SenX Technology, LLC
Midland, Michigan USA**

Rev 021603

))) *FirstLook* Automotive Engine Diagnostic Sensor “The Pulse of Your Engine”

1. Introduction

Congratulations on your purchase of the *FirstLook*TM automotive engine diagnostic sensor. This is your first step down a road of easier and more accurate engine diagnostics. With *FirstLook* you can now have a more complete picture of an engine’s performance, quickly and easily. Once you have learned to use the sensor combined with the timing chart you will be able to find burnt valves, bad injectors and other engine performance problems without major disassembly of the engine...and in a fraction of the time currently required. Consider how long it may take just to remove spark plugs to perform a compression test on today's engines.

FirstLook is unique because it looks at pulses in engine airflow, allowing you to display “the pulse of your engine” on standard scope equipment. While scanners interrupt the information they receive from engine sensors and engine analyzers tell us what the ignition system is doing, it is difficult to see what was *actually* happening in the engine without intrusive tests. With *FirstLook* in your diagnostic arsenal it will now be possible to see what is dynamically occurring in your engine. Although this user's guide will focus on automobile combustion engines, the *FirstLook* sensor may also be used with other gasoline and diesel four stroke engines.

2. Overview

Please take a few minutes to become familiar with the many capabilities of *FirstLook*. A few minutes now will help you save hours of diagnostic time later. This user's guide is divided into the following sections.

- Theory and Operation
- Sensor Setup
- Lab Scope Basics
- Quick Tests
- Triggered Tests
- Timing Chart Interpretations
- Waveform Analysis

3. Theory of Operation

The *FirstLook* sensor looks at the airflow pulses generated by the normal operation of internal combustion engine as shown in Figure 1.

Exhaust or Vacuum Side of Engine



Pulses vary over time depending upon the stroke cycle of engine

Figure 1

The sensor detects these pulse waves through either the exhaust or vacuum sides of the engine. All engines produce a predictable pattern of these pulses which can easily be displayed on most commercially available lab scopes when connected to FirstLook. This pulse wave is sensed and the voltage is output for display by the lab scope. Changes or irregularity in this predictable pattern may be traced back to problems in the engine. The pulse wave can also be affected by unburned fuel in the exhaust and this abnormality is also detected and displayed. **The FirstLook sensor does not require any external source of power, so you never need to purchase or replace batteries.**

4. Sensor Setup

Setup is very straightforward.

1. Remove sensor and cabling from package (Figure 2)
2. Install appropriate cable (25 ft. BNC or 45 in. Banana) to BNC connector on sensor (Cable selection depends upon the lab scope you will be using)
3. Install BNC connector (or banana plug) on other end of cable to your lab scope
4. Lab scope settings will be discussed in the next section

Package Contents




Figure 2

5. Lab Scope Basics

The use of a lab scope allows us to look at how voltage is affected over a period of time. When using the FirstLook sensor the time scale most commonly used will be milliseconds (ms) Voltage scales on the lab scope will typically be in the volts range for sensor readings and in the kilovolts range for ignition triggers. Note that there are "dividers" built into ignition triggers that allow displays in the volts range, even though the actual is kilovolts. Let's take a look at a common lab scope setup in Figure 3.




Figure 3

On the left side of the chart we see a vertical number, denoting voltage on Channel 1 (or A) of this lab scope. This is a 5 volt AC scale, and we are looking at equal voltage above and below the zero or center line. On the right we see a 5 volt AC scale on Channel 2 (or B). The voltage shows 2 volts/division on Channel 1, and 1 volt/division on Channel 2. The bottom line on the chart is a time line, in this case 20ms/division. This can also be described as 200ms scale.

Note that in figure 4 below Channel 1 is set at a .5 volts AC scale (.1volt/division) and Channel 2 is set at a 50mv AC scale (10mv/division). For further lab scope theory refer to your lab scope operation manual.

In this chart we are looking at the actual ignition trigger signal on Channel 1 and the sensor output on Channel 2. By looking at the two signals over the same time base variations in sensor output can be correlated with the ignition trigger reference signal. In combination with the automotive engine timing chart (see Figure 12) specific engine problems can be diagnosed and referenced to a specific cylinder.

Timing reference lines are used to measure differences in time on the signal patterns. In Figure 4 below, these reference lines are labeled "x" and "o" and are placed at specific points on the signal time base. These are shown at the top of the chart and will become important for analyzing patterns with the timing chart.

Reference cursor	x = 133.50 ms
Reference cursor	o = 56.99 ms
Time between reference points	xo = 76.54 ms (difference due to rounding)




Figure 4

6. Quick Tests

These quick tests can be run on any engine that has the ability to be cranked over at sufficient rpm to start normally. This simple test can be your first insight into overall engine condition. The test should only be used as a starting point for diagnosis.

Quick Test #1 - Cranking Engine - Exhaust Test (without a trigger)

This test is useful when testing "no start" vehicles and as a first diagnostic test to check general engine mechanical condition.

To perform this test:

1. Insert sampling hose into exhaust pipe 4 inches
2. Set time base scale on lab scope to 600ms
3. Set voltage scale on lab scope to 500mv AC
4. **DISABLE** FUEL SYSTEM
5. Crank engine until display pattern stabilizes
6. Save pattern

Note: Time base and voltage scales are a recommended starting point for this test. Adjust to achieve best signal display on your lab scope.

Figure 5 shows a typical cranking engine pattern as seen through the exhaust pipe.




Figure 5

This pattern shows a consistent cranking pattern on Channel 1.

Quick Test #2 - Cranking Engine - Vacuum Test (without a trigger)

This test is useful for finding intake valve problems and vacuum leaks.

To perform this test:

1. Place sampling hose on PCV port or any other good vacuum source
2. Set time base scale on lab scope to 600ms
3. Set voltage scale on lab scope to 5v AC
4. **DISABLE** FUEL SYSTEM
5. Crank engine until display pattern stabilizes
6. Save pattern

Note: Time base and voltage scales are a recommended starting point for this test. Adjust to achieve best signal display on your lab scope.

Figure 6 is an example of a cranked engine vacuum pattern as seen from a brake booster vacuum line on a GM 3800 engine.




Figure 6

This pattern shows general valve condition and cylinder compression.

Quick Test #3 - Engine Idle Test (without a trigger)

This test is useful in determining the general condition of the combustion cycle of a running engine to assess a starting point for further diagnosis.

To perform this test:

1. Insert sampling hose into exhaust pipe 4 inches
2. Set time base scale on lab scope to 200ms
3. Set voltage scale on lab scope to 2v AC
4. Start engine and warm up. Allow idle and display pattern to stabilize.
5. Save pattern

Note: Time base and voltage scales are a recommended starting point for this test. Adjust to achieve best signal display on your lab scope.

Figure 7 is an example of an engine idle test pattern without a trigger as seen through the exhaust pipe.




Figure 7

Figure 7 shows the general condition of a running engine. By comparative analysis of signal levels above and below the time axis, relative cylinder performance and general condition of the engine may be quickly determined. This test may be done with or without the ignition trigger. Engine test was run on a GM 3800 engine with 160,000 miles. General condition of engine is good as we do not see any major dropouts in the scope pattern. **Scope patterns will not always be perfect - what we are looking for is major deviations from the other cylinders.** This will be discussed and later.

7. Triggered tests

A triggered test allows you to find cylinder specific information by triggering off a repeatable signal generated by engine. Ignition scope triggering can be accomplished in different ways including ignition triggering (most common), current ramping using a low current probe and an injector or coil signal. For the triggered tests described below the trigger will be obtained from the firing provided by cylinder number 1.

It is mandatory that all engine ignition issues are first resolved before running a triggered test. This is because defective or improperly functioning ignition systems can cause trigger problems and potential misdiagnosis. Once all ignition functions are properly resolved, triggered testing can provide highly useful information.

Triggered Test #4 - Triggered Cranking Exhaust Test

This test is useful when it is desirable to obtain cylinder specific data without the engine running. Exhaust valve action per cylinder and problems with the head or head gaskets may be assessed. **Do not run this test on a carbureted engine.**

To perform this test:

1. Insert sampling hose into exhaust pipe 4 inches
2. Connect ignition trigger from lab scope to cylinder number 1
3. Set time base scale on lab scope to 600ms
4. Set voltage scale for Channel 1 on lab scope to 1v AC
5. Set voltage scale for Channel 2 on lab scope to 5v AC for trigger
6. **DISABLE FUEL SYSTEM (May not be possible on a carbureted engine)**
7. Crank engine until display pattern stabilizes
8. Save pattern

Note: Time base and voltage scales are a recommended starting point for this test. Adjust to achieve best signal display on your lab scope.

Figure 8 shows an example of a triggered cranking pattern as seen through the exhaust




Figure 8

Figure 8 shows a consistent signal pattern on Channel 1 as triggered against Channel 2 on the same time line. Cursor lines are added to show trigger reference (sparkplug #1) and show a 459.2ms time between trigger events. In a later section we will discuss the timing chart and determine that the approximate cranking speed of this engine is 275 rpm.

Triggered Test #5 - Triggered Cranking Vacuum Test from Vacuum Source

This test is useful in the assessment of the intake air and valve system for cylinder specific defects on the intake side of the engine. **Do not run this test on a carbureted engine.**

To perform this test:

1. Insert sampling hose onto PCV port, brake booster or best vacuum source
2. Connect ignition trigger from lab scope to cylinder number 1
3. Set time base scale on lab scope to 600ms
4. Set voltage scale for Channel 1 on lab scope to 5v AC
5. Set voltage scale for Channel 2 on lab scope to 5v AC for trigger
6. **DISABLE FUEL SYSTEM (May not be possible on a carbureted engine)**
7. Crank engine until display pattern stabilizes
8. Save pattern

Note: Time base and voltage scales are a recommended starting point for this test. Adjust to achieve best signal display on your lab scope.

Figure 9 shows an example of a vacuum pattern as seen from the brake booster vacuum line..




Figure 9

Triggered Test #6 - Engine Idle Test (with a trigger)

This test is useful in the assessing overall engine condition taking into account the fuel delivery system.

To perform this test:

1. Insert sampling hose into exhaust pipe 4 inches
2. Connect ignition trigger from lab scope to cylinder number 1
3. Set time base scale on lab scope to 200ms
4. Set voltage scale for Channel 1 on lab scope to 2v AC
5. Set voltage scale for Channel 2 on lab scope to 5v AC for trigger
6. Start engine and warm up. Allow idle and display pattern to stabilize.
7. Save pattern

Note: Time base and voltage scales are a recommended starting point for this test. Adjust to achieve best signal display on your lab scope.

Figure 10 shows an example of an idle test as seen from the exhaust:




Figure 10

Notice the time between firing events 170.5 ms, this engine is idling at 700 RPM.

Triggered Test #7 - Braked Engine Load Test (with or without a trigger) on exhaust or vacuum

This test is useful in locating intermittent engine problems occurring at higher engine rpm under load on automobiles with automatic transmissions only.

To perform this test:

1. Insert sampling hose into exhaust pipe 4 inches (or attach to PCV port or other vacuum port)
2. Connect ignition trigger from lab scope to cylinder number 1 (optional)
3. Set time base scale on lab scope to 200ms
4. Set voltage scale for Channel 1 on lab scope to 2v AC
5. Set voltage scale for Channel 2 on lab scope to 5v AC for trigger
6. Start engine and warm up. Allow idle and display pattern to stabilize.
7. **SET PARKING BRAKE**
8. **APPLY FOOT PRESSURE ON BRAKE PEDAL**
9. Place transmission in DRIVE
10. Raise engine rpm until problem appears but no higher than 1500 rpm maximum
11. Save pattern
12. Return engine to idle and **place transmission in PARK**

Important Safety Note: This test should only be carried out with 2 people. The 1st person should be responsible for running the diagnostic equipment outside the vehicle and the 2nd person for vehicle operation inside the vehicle.

Note: Time base and voltage scales are a recommended starting point for this test. Adjust to achieve best signal display on your lab scope.

Figure 11 is an example of a braked engine power test as seen from the exhaust. This example is a GM 3800 engine with coil pack ignition. Engine speed is 1500 rpm, time between trigger events is 78.5 ms. This looks to be a normal pattern for coil pack ignition systems.




Figure 11

8. Automotive Engine Timing Chart

The timing chart shown in Figure 12 is the key to the diagnostic power behind the FirstLook sensor by correlating the timing of engine events to the visual display. Data is shown for specific cylinder configurations.

- The leftmost column in the chart shows engine speed in Revolutions per Minute (rpm).
- The data in columns A to F is the time between valve opening events for a given engine with 2 to 10 cylinders per 1 Cycle of a 4 stroke engine.
- The next column, Time to Complete 1 Cycle is the total time in milliseconds to complete all firing events in a specific engine at the given rpm. Note that 2 revolutions equal 1 cycle in a 4 stroke engine. This is also the total time window that needs to be open to see the complete firing cycle of all cylinders. If it is necessary to look at multiple cycles, adjust your lab scope to a time base that allows for viewing of multiple cycles of the engine.
- Starting Time Base References are suggested for specific tests in the right most column.

Automotive Engine Timing Chart for Four Cycle Engines

Engine Speed (rpm)	Time Between Valve Opening Events (milliseconds)						Time to Complete 1 Cycle in 4 Stroke Engine (ms)	Starting Time Base Reference (ms)
	A	B	C	D	E	F		
	2 Cylinder	4 Cylinder	5 Cylinder	6 Cylinder	8 Cylinder	10 Cylinder		
150	400.0	200.0	160.0	133.3	100.0	80.0	800.0	
175	342.9	171.4	137.1	114.3	85.7	68.6	685.7	cold crank
200	300.0	150.0	120.0	100.0	75.0	60.0	600.0	600
225	266.7	133.3	106.7	88.9	66.7	53.3	533.3	
250	240.0	120.0	96.0	80.0	60.0	48.0	480.0	
300	200.0	100.0	80.0	66.7	50.0	40.0	400.0	
350	171.4	85.7	68.6	57.1	42.9	34.3	342.9	
400	150.0	75.0	60.0	50.0	37.5	30.0	300.0	
450	133.3	66.7	53.3	44.4	33.3	26.7	266.7	
500	120.0	60.0	48.0	40.0	30.0	24.0	240.0	
550	109.1	54.5	43.6	36.4	27.3	21.8	218.2	idle start
600	100.0	50.0	40.0	33.3	25.0	20.0	200.0	200
650	92.3	46.2	36.9	30.8	23.1	18.5	184.6	
700	85.7	42.9	34.3	28.6	21.4	17.1	171.4	
750	80.0	40.0	32.0	26.7	20.0	16.0	160.0	
800	75.0	37.5	30.0	25.0	18.8	15.0	150.0	
850	70.6	35.3	28.2	23.5	17.6	14.1	141.2	
900	66.7	33.3	26.7	22.2	16.7	13.3	133.3	
950	63.2	31.6	25.3	21.1	15.8	12.6	126.3	
1000	60.0	30.0	24.0	20.0	15.0	12.0	120.0	
1100	54.5	27.3	21.8	18.2	13.6	10.9	109.1	low rpm
1200	50.0	25.0	20.0	16.7	12.5	10.0	100.0	100
1300	46.2	23.1	18.5	15.4	11.5	9.2	92.3	
1400	42.9	21.4	17.1	14.3	10.7	8.6	85.7	
1500	40.0	20.0	16.0	13.3	10.0	8.0	80.0	
1600	37.5	18.8	15.0	12.5	9.4	7.5	75.0	
1700	35.3	17.6	14.1	11.8	8.8	7.1	70.6	
1800	33.3	16.7	13.3	11.1	8.3	6.7	66.7	
1900	31.6	15.8	12.6	10.5	7.9	6.3	63.2	
2000	30.0	15.0	12.0	10.0	7.5	6.0	60.0	
2100	28.6	14.3	11.4	9.5	7.1	5.7	57.1	
2200	27.3	13.6	10.9	9.1	6.8	5.5	54.5	
2300	26.1	13.0	10.4	8.7	6.5	5.2	52.2	mid range rpm
2400	25.0	12.5	10.0	8.3	6.3	5.0	50.0	50

Figure 12

Let's take a look at some examples of how to use the timing chart to dissect a waveform.

Figure 13 below shows an idle pattern of a GM 3800 6 cylinder engine with a Firing Order 1-6-5-4-3-2




Figure 13

Looking at Figure 13 and the timing chart you can see that with 160ms between firing or trigger events the engine rpm is 750rpm. Using the (column D) timing chart in Figure 12 we can also determine that a single cylinder will show up in a 26.7ms window.

IMPORTANT

*The sensor signal is delayed in relation to the engine firing order. In other words, the sensor signal has a delay in the exhaust of 1 cylinder for a 4 cylinder engine and 2 cylinders for a 6 or 8 cylinder engines. It is important to note that the number 1 plug firing is the event to which we are triggering the display. The cylinder must rotate 180 degrees to begin the exhaust phase of the cycle...this accounts for the offset we see in our display. In the pattern in Figure 14 we see the timing spike at the point the number 1 plug fires. **The result of what happens in the cylinder is not seen until a 180 degree rotation of the crankshaft has taken place and the opening of the exhaust valve occurs. This is seen as an offset to the right of trigger (plug #1) for exhaust readings and as an offset to the left for trigger (plug #1) for vacuum readings.***




Figure 14

For example in Figure 14 if the engine firing order is 1,6,5,4,3,2 and the trigger is on cylinder #1, then the scope pattern as seen through the exhaust is read as 3,2,1,6,5,4 after taking into account the required cylinder offset.

It is important to note that changes in timing advance, pipe length and effects of tuned exhaust will have an impact on waveform outputs. Some waveforms will be almost perfect but others will show the effect of a tuned exhaust system as seen in Figure 14. Engine problems will always cause a fluctuation of the waveform that extends above or below the average of the other cylinders. This is where comparative analysis of cylinders becomes important. In general the more symmetrical the waveform and distribution above and below the zero reference line, the better the condition of the engine.

Conditions caused by lack of fuel or lean burn will cause a drop-out in the waveform. Problems resulting in excess fuel (dirty injectors, poor combustion, dirty plugs, plug wire problems) will show up as a drop-out in the waveform followed by an increase in waveform above zero as the engine works to compensate for the excess fuel as it is burned in the manifold (as shown in Figure 14). This is the work of the computer and oxygen sensor in today's engines.

The following charts depict the cylinder offset of 4, 6, and 8 cylinder engines in sensor waveforms obtained through the exhaust pipe of the engine.

Figure 15 shows a Honda Accord 4 cylinder engine as viewed through the exhaust port at idle. This is good example of a clean waveform and ignition timing reference as displayed on a lab scope. The pattern is symmetrical and the amplitude of the waveform is equal above and below the zero reference line. Only minor noise is seen as the engine airflow pulses move through the muffler and catalytic converter. This waveform also shows the slight offset caused by engine advance timing and effect of compressibility and tailpipe length.




Figure 15

Figure 16 below is a 4 cylinder engine at 1000 RPM per the timing chart with 30 ms between exhaust events. The shaded half of arrow is the combustion cycle. The unshaded half is the exhaust cycle.




Figure 16

Figure 17 shows a 6 cylinder engine at 1000 RPM per the timing chart 20 ms between exhaust events. Shaded half of arrow is the combustion cycle. The unshaded half is exhaust cycle.




Figure 17

Figure 18 below is an 8 cylinder engine at 1000 RPM per the timing chart with 15 ms between exhaust events. Shaded half of arrow is the combustion cycle. The unshaded half is the exhaust cycle.




Figure 18

9. Waveform Analysis

We have learned how the timing chart is used and how the firing order is offset from trigger reference. This offset applies no matter what four stroke internal combustion engine you are working with. In this section we will become familiar with how to use the information gathered with the lab scope and look at several waveforms and the information contained within.




Figure 19

The waveform in Figure 19 shows a six cylinder engine with a repeating problem. Starting from the first trigger point (X) we see a 57.86ms time elapsed between trigger events. This tells us, by looking at the timing chart (Figure 12), that the pattern was taken at an engine speed of approximately 2100rpm. Looking at the timing chart for a 6 cylinder engine we can determine that each cylinder occupies approximately 9.5ms of the time between trigger reference points. In Figure 20 we divide the window and see which cylinder has the problem.




Figure 20

The firing order for this engine is 1,6,5,4,3,2. With the trigger on cylinder #1, then the scope pattern as seen through the exhaust is read as 3,2,1,6,5,4 after taking into account the required cylinder offset. So the first spacing between o and x is cylinder number 3. Now we can easily see that the next cylinder in the order or cylinder number 2 is where the problem lies. The waveform in Figure 21 verifies this finding. With the cursors over this area we have now quickly determined the problem cylinder.




Figure 21

Next let's interpret another diagnostic waveform in Figure 22.




Figure 22

The pattern displayed in Figure 22 is from a GM 3800 V-6. By looking at the automotive timing chart we can determine that the engine speed is approximately 850 rpm. If we look at the chart we will find that the cylinder spacing is 23.5ms. Also knowing the cylinder offset is two cylinders we determine that the firing order on the display is 3, 2, 1, 6, 5, 4. So let's look at the first 23.5ms division on the pattern (Figure 23).




Figure23

The drop-out in this pattern is occurring on cylinder number 3. Looking farther to the right at the next trigger reference point you can see the pattern repeat itself. Also if you look just after the dropout you can see the engine compensating for the loss of power in cylinder number 3.

Lastly, let's look at a cranking waveform pattern (Figure 24).




Figure 24

Figure 24 is a good example of a cranking test on an engine that is in very good condition. Notice the symmetry in the waveform, showing good performance throughout the test. The timing we are seeing between trigger references is 458.5ms, which makes the cranking rpm of this engine approximately 260rpm as referenced by the timing chart.

These patterns should give you a good starting point for your engine diagnostics. Check with our web site www.senxtech.com for future examples. Thank you again for your investment in the **FirstLook Automotive Engine Diagnostic Sensor**.

10. Support and Warranty

Support

For support questions or warranty assistance contact:

SenX Technology, LLC
738 South Poseyville Road
Midland, MI 48640
Phone 989-832-8898 Fax 989-832-8908
Or visit our web site at <http://senxtech.com>

Warranty

SenX Technology, LLC warrants the products described herein for a period of 1 year under normal use and service from the date of purchase, that the product will be free of defects in material and workmanship. This warranty does not cover ordinary wear and tear, abuse, misuse, overloading, altered products, or damage caused by the purchaser connecting the unit incorrectly.

THERE IS NO WARRANTY OF MERCHANTABILITY. THERE ARE NO WARRANTIES WHICH EXTEND BEYOND THE DESCRIPTION HEREIN. THERE ARE NO WARRANTIES EXPRESSED OR IMPLIED OR ANY AFFIRMATION OF FACT OR REPRESENTATION EXCEPT AS SET FORTH HEREIN.

REMEDY

SenX Technology, LLC sole responsibility and liability, and purchaser's exclusive remedy shall be limited to the repair or replacement at SenX Technology option, of a part or parts not conforming to the warranty. All products requiring warranty service shall be returned to SenX Technology within 1 year of purchase, shipping prepaid. SenX Technology will return repaired or replaced products to the purchaser via prepaid ground transportation. In no event shall SenX Technology be liable for damages of any nature, including incidental or consequential damages, including but not limited to any damages resulting from non-conformity, defect in material or workmanship.

Neither SenX Technology LLC nor its affiliates shall be liable to the purchaser of this product or third parties for damages, losses, costs, or expenses incurred by the purchaser or third parties as a result of: accident, misuse, or abuse of this product or unauthorized modifications, repairs, or alterations to this product, or failure to strictly comply with SenX Technology's operating and maintenance instructions.

No part of this publication may be reproduced, stored in a retrieval system, or transmitted in any form or by any means, electronic, mechanical, photocopying, recording, or otherwise, without the prior written permission of SenX Technology, LLC.

FirstLook™ and SenX™ Technology are trademarks of SenX Technology, LLC